Gudmund Oskar

Pant Marker Instructions



- 1. Place the bottom cutout of the Pant Marker around the shoe so the ruler is straight up and the bottom touches the floor.
- 2. Place the ruler against the back leg and make a chalk mark on the pant at the top of ruler. Repeat for each pant leg. (The total height of the Pant Marker is 15" tall.)
- 3. Lay pants on table. Line up the two back leg marks that you made on each leg. Mark the bottom hem length. This mark captures any legs that are uneven, different lengths.



